



Ask for quote

Face shield, reusable

Face shield & Goggles

Visor for protection against droplets and splashes of liquids. Made in Scandinavia. 60 pcs/box. Tested and approved according to CE EN166.. Visor cleaning is best done with microfibre cloth, water and soap. Soap with abrasive will scratch the visor. Avoid prolonged cleaning with alcohol-based products. It may affect the transparency of the visor. Printed instructions in each box. The product can be used several times. Restrictions on use The visor does not protect against steam that may enter under the visor. The visor does not purify inhaled air. The visor is not intended to be used as a shock / impact protection. The product is not intended to be sterilized. The product can be used repeatedly until the visor has a matte or scratched surface. Then the product is discarded. The product should not be stored in direct sunlight or in high heat. Under normal use, the product can be used for just over a year.

Color



Material

PP nature, Green MB (food grade material), PET

Produktsens-hojd

250 mm

Produktsens-vikt

75 g

Box

No

Statistik-nummer

3926 90 97 90

Antal-ytterkartong

60 pcs

Kartong-bruttovikt

6,5 kg

Minsta-antal

100 pcs

Leveranstid

From stock

Ursprungsland

Denmark